
MXQR Series 06, 08, 012 016, 020, 025



Construction



* The numbers correspond with those in the "Construction" of the MXQR series in the Web Catalog.

Seal Kit List

No.	Description	Material	Note
18	Piston seal		
19	Rod seal	NBR	
20	O-ring		

Replacement Parts: Seal Kit

Bore size (mm)	Part no.	Contents
6	MXQ6-PS	
8	MXQ8-PS	
12	MXQ12-PS	Set of nos.
16	MXQ16-PS	18, 19, 20
20	MXQ20-PS	
25	MXQ25-PS	

^{*} The seal kit includes these seals to provide as a set. Order the seal kit based on each bore size.

Replacement Parts: Grease Pack

	ricpiacement i a	its. Gicase i ac	
	Applied part	Grease pack part no.	
_	Guide unit	GR-S-010 (10 g)	
	Guide unit	GR-S-020 (20 g)	
	Culinday unit	GR-L-005 (5 g)	
	Cylinder unit	GR-L-010 (10 a)	