
Air Cylinder/With End Lock

MBB Series 032, 040, 050 063, 080, 0100



Construction

Locking at head end Manual release non-locking type: N



- * The numbers correspond with those in the "Construction" of the MBB series in the **Web Catalog**.
- * Replaceable with the rod boot assembly

For details on replacement part numbers, refer to page 245.

Seal Kit List

No.	Description	Material	Note
29	Cushion seal	Urethane	
30	Rod seal	NBR	
31)	Piston seal	NBR	
32	Cylinder tube gasket	NBR	
33	Lock piston seal	NBR	

Replacement Parts: Seal Kit

Bore size (mm)	Part no.	Contents				
Locking at head or rod end						
32	MBB32-PS					
40	MBB40-PS	Set of nos.				
50	MBB50-PS					
63	MBB63-PS	29, 30, 31, 32, 33				
80	MBB80-PS					
100	MBB100-PS					

Locking at both ends

32	MBB32-PS-W	
40	MBB40-PS-W	
50	MBB50-PS-W	Set of nos.
63	MBB63-PS-W	29, 30, 31, 32, 33
80	MBB80-PS-W	
100	MBB100-PS-W	

- \ast Seal kits consist of items ${\mathfrak A}$ to ${\mathfrak A},$ and can be ordered by using the seal kit number corresponding to each bore size.
- * The trunnion type should not be disassembled.
- * The seal kit includes a grease pack (ø32 to ø50: 10 g, ø63, ø80: 20 g, ø100: 30 g).

Order with one of the following part numbers when only the grease pack is required.

Grease pack part no.: GR-S-010 (10 g), GR-S-020 (20 g)

