
CQP2 Series 912, 916, 920, 925 932, 940, 950, 963 980, 9100




Construction


Without auto switch magnet



A-A section (port on rod end)



With auto switch magnet



A-A section (port on rod end)

* The numbers correspond with those in the "Construction" of the CQ2 series in the Web Catalog.

Seal Kit List

No.	Description	Material	Note
12	Piston seal		
13	Rod seal	NBR	
(14)	Gasket		

Replacement Parts: Seal Kit

neplacement raits. Seal Kit			
Part no.	Contents		
(non-lube)			
CQ2B12-PS			
CQ2B16-PS			
CQ2B20-PS			
CQ2B25-PS			
CQ2B32-PS	Set of nos.		
CQ2B40-PS	12, 13, 14		
CQ2B50-PS			
CQ2B63-PS			
CQ2B80-PS			
CQ2B100-PS			
	Part no. (non-lube) CQ2B12-PS CQ2B16-PS CQ2B20-PS CQ2B25-PS CQ2B32-PS CQ2B40-PS CQ2B50-PS CQ2B50-PS CQ2B50-PS CQ2B63-PS CQ2B80-PS		

Air-hydro type

20	CQ2BH20-PS	
25	CQ2BH25-PS	
32	CQ2BH32-PS	
40	CQ2BH40-PS	Set of nos.
50	CQ2BH50-PS	12, 13, 14
63	CQ2BH63-PS	
80	CQ2BH80-PS	
100	CQ2BH100-PS	

^{*} The seal kit includes ②, ③, ④. Order the seal kit based on each bore size.

Grease pack part no.: GR-S-010 (10 g)

Rotary Actuators Air Grippers

Modular F.R.L

Air Preparation Equipment

Industrial Filters

Replacement Procedure

Actuators

Rotary Actuators Air Grippers



^{*} Since the seal kit does not include a grease pack, it should be ordered


Compact Cylinder/Axial Piping: Single Acting, Single Rod

CQP2 Series Ø12, Ø16, Ø20, Ø25 Ø32, Ø40, Ø50




Construction


Spring return



A-A section For the single acting type, the supply/ exhaust port is on the spring side.



Spring extend



A-A section (Port on rod end)

* The numbers correspond with those in the "Construction" of the CQ2 series in the Web Catalog.

Seal Kit List

No.	Description	Material	Note
14)	Piston seal		
15	Rod seal	NBR	
16	Gasket		

Replacement Parts: Seal Kit

Bore size (mm)	Part no.	Contents	
Single acting, spring return			
12	CQ2B12-S-PS		
16	CQ2B16-S-PS		
20	CQ2B20-S-PS		
25	CQ2B25-S-PS	No. 🕩	
32	CQ2B32-S-PS		
40	CQ2B40-S-PS		
50	CQ2B50-S-PS		

^{*} Since the seal kit does not include a grease pack, it should be ordered

Grease pack part no.: GR-S-010 (10 g)

Replacement Parts: Seal Kit

neplacement Parts. Sear Kit				
Bore size (mm)	Part no.	Contents		
Single acting, spring extend				
12	CQ2B12-T-PS			
16	CQ2B16-T-PS			
20	CQ2B20-T-PS	Set of nos.		
25	CQ2B25-T-PS	(4), (15), (16)		
32	CQ2B32-T-PS	19, 19, 10		
40	CQ2B40-T-PS			
50	CQ2B50-T-PS			

^{*} The seal kit includes 4, 5, 6. Order the seal kit based on each bore size.

Grease pack part no.: GR-S-010 (10 g)



^{*} Since the seal kit does not include a grease pack, it should be ordered separately.