



Series Variations

CG3 Series

Sorias	Action			E	Bore siz	ze [mm]	Cushion	Standard stroke [mm]			
Selles	Action	20	25	32	40	50	63	80	100	Cushion	Standard Stroke [mm]	
Air cylinder/Short type CG3 series	Double acting, Single rod	•	•	•	•	•	•	•	•	Rubber bumper	ø20: 1 to 200 ø25 to ø100: 1 to 300	



Air Cylinder Short Type **Standard: Double Acting, Single Rod** CG3 Series RoHS ø20, ø25, ø32, ø40, ø50, ø63, ø80, ø100



For applicable auto switches, refer to the table below

Applicable Auto Switches / Refer to the Web Catalog for further information on auto switches.

							ao	Au	ito switch mod	lel	1.000	d wiro	longt	h (m)																				
Tuno	Special	Electrical	or i	Wiring	LC		ye	Ар	plicable bore s	ize	Leau	JWIE	lengt		Pre-wired	Applica	Applicable load																	
Type	function	entry	icat	(Output)	DC		10	ø20 to	ø20 to ø63		0.5	1	3	5	connector	Applicable load																		
			pul				AC	Perpendicular	In-line	In-line	(Nil)	(M)	(L)	(Z)																				
				2 wire (NDN)				M9NV	M9N	-				0	0																			
				S-WIE (INFIN)		5 V 10 V		-	-	G59		-		0	0	IC																		
	_	Crommot		2 wire (DND)		5 V, 12 V		M9PV	M9P	—			•	0	0	circuit																		
tc	Gronniner		S-WITE (PINP)				-	-	G5P		-		0	0]																			
			Quuiro		10.1/		M9BV	M9B	_			٠	0	0	_																			
Ň	iw s			2-wire		12 V		-	-	K59		-		0	0																			
0							M9NWV	M9NW	_			٠	0	0																				
aut	Diagnostic	Diagnostic ndication (2-color indicator) Grommet	ŝ	S-WIRE (INPIN)	04.14	5 V 12 V	_	-	-	G59W		-		0	0	IC	Relay,																	
te	indication		×	2 wire (DND)	24 V	5 V, 12 V		M9PWV	M9PW	_			٠	0	0	circuit	PLC																	
sta	(2-color		Grommot	Crommot	Crommat	Grammat	Crommot	Crommot	Crommot	Crommot	Crommat	Crammat	Crommot	Crommot	Crommot	Crommat	Crommot	Crommat	Grammat		S-WITE (PINP)				-	-	G5PW		-	٠	0	0	1	
id	indicator)																			Grommot	Grommet		2-wire		10.1	1	M9BWV	M9BW	_				0	0
Sol			irommet	let	2-wire		12 V		-	-	K59W		-	٠	0	0	1 -																	
		1		3-wire (NPN)		EV 10 V		M9NAV*1	M9NA *1	—	0	0	٠	0	0	IC																		
	Water resistant			3-wire (PNP)		5 V, 12 V		-				M9PAV*1	M9PA *1	_	0	0	٠	0	0	circuit														
	(2-color indicator)			0		10.1/						M9BAV*1	M9BA*1	—	0	0		0	0															
				2-wire		12 V		-	-	G5BA*1	-	-		0	0	1 –																		
•			ŝ	3-wire (NPN equivalent)	-	5 V	-	A96V	A96	—			٠		0	IC circuit	—																	
ъt			×				100 V	A93V	A93	_					0*2	—																		
switch =	-	Grommet	٩	Quuiro		10.1	100 V or less	A90V	A90	—			٠		0*2	IC circuit	Relay,																	
		Ker Norman	2-wire	24 V	12 V	100 V, 200 V	-	_	B54		-			-	_	PLC																		
щ	ž							No Yee			2			200 V or less	-	_	B64		-	٠	-	—	_											

*1 Water resistant type auto switches can be mounted on the above models, but in such case SMC cannot guarantee water resistance.

A water-resistant type cylinder is recommended for use in an environment which requires water resistance.

*2 The load voltage used is 24 VDC.

1

- * Lead wire length symbols: 0.5 m ······Nil (Example) M9NW
 - 1 m ……M (Example) M9NWM
 - 3 m ……L (Example) M9NWL (Example) M9NWZ
 - 5 mZ
 - None ······N (Example) H7CN

* Since there are applicable auto switches other than those listed above, refer to page 12 for details.

For details on auto switches with pre-wired connectors, refer to the Web Catalog.

D-A9 (V)/M9 (V)/ are assembled before shipment.)

* Auto switches marked with a "O" are produced upon receipt of order.







Refer to pages 9 to 13 for cylinders with auto switches.

- · Auto Switch Proper Mounting Position (Detection at stroke end) and Mounting Height
- Minimum Stroke for Auto Switch Mounting · Auto Switch Mounting Brackets/Part Nos.
- · Operating Range
- · Cylinder Mounting Bracket, by Stroke/ Auto Switch Mounting Surfaces



Symbol	Specifications
-XA□	Change of rod end shape

Specifications

Bore size [mm]	20	25	32	40	50	63	80	100			
Action	Double acting, Single rod										
Lubrication		Not required (Non-lube)									
Fluid		Air									
Proof pressure	1.0 MPa										
Max. operating pressure	0.7 MPa										
Min. operating pressure	0.05 MPa										
Ambient and fluid		Without	auto sw	itch: -10)°C to 7	0°C (No	freezing)			
temperatures	With auto switch: -10°C to 60°C (No freezing)										
Piston speed ^{*1}			50 to 10	00 mm/s	3		30 to 70	00 mm/s			
Stroke length tolerance	+1.4 mm										
Cushion	Rubber bumper										
Mounting	Basic, Foot bracket, Rod flange, Head flange, Clevis										
Concepts the optimizer within the ellowable kinetic energy. Defor to more 4 for details											

* Operate the cylinder within the allowable kinetic energy. Refer to page 4 for details.

Standard Strokes

Bore size [mm]	Standard stroke [mm]*1
20	25, 50, 75, 100, 125, 150, 200
25	
32	
40	
50	25, 50, 75, 100, 125, 150, 200, 250, 300
63	
80	
100	

*1 The manufacturing of intermediate strokes in 1 mm increments is possible. (Spacers are not used.)

Accessories

	Mounting	Basic	Foot bracket	Rod flange	Head flange	Clevis
Standard	Rod end nut (male thread)	•	•	•	•	•
Standard	Clevis pin	—	—	_	-	•
	Single knuckle joint	٠	•	•	•	•
Option	Double knuckle joint (with pin)* ¹	•	•	•	•	•
	Pivot bracket	—	_	_	_	•

 $\ast 1~$ A double knuckle joint pin and retaining rings are shipped together.

* For part numbers and dimensions, refer to page 8.

Mounting Brackets/Part Nos.

			-							
Mounting	Order			Contonte						
bracket	qty.	20	25	32	40	50	63	80	100	Contents
Foot bracket	2*1	CG-L020	CG-L025	CG-L032	CG3-L040	CG-L050	CG-L063	CG-L080	CG-L100	2 foot brackets, 8 mounting bolts
Flange	1	CG3-F020A	CG3-F025A	CG-F032	CG3-F040	CG-F050A	CG-F063A	CG-F080	CG-F100	1 flange, 4 mounting bolts
Clevis	1	CG-D020	CG-D025	CG-D032	CG3-D040	CG-D050	CG-D063	CG-D080	CG-D100	1 clevis, 4 mounting bolts, 1 clevis pin, 2 retaining rings
Pivot bracket	1	CG-020- 24A	CG-025- 24A	CG-032- 24A	CG-040- 24A	CG-050- 24A	CG-063- 24A	CG-080- 24A	CG-100- 24A	1 pivot bracket

*1 When ordering foot brackets, order two pieces per cylinder.



Mounting Brackets, Accessories/Material, Surface Treatment

Segment	Description	Material	Surface treatment
	Foot bracket	Carbon steel	Nickel plating
Mounting brackets	Flores	Carbon steel (ø20 to ø63)	Nickel plating
	Flange	Cast iron (ø80, ø100)	Nickel plating
	Clavia	Carbon steel (ø20 to ø63)	Nickel plating
	Cievis	Cast iron (ø80, ø100)	Nickel plating
	Rod end nut	Carbon steel	Zinc chromating
	Single knuckle jeint	Carbon steel (ø20 to ø32)	Nickel plating
	Single knuckle joint	Cast iron (ø40 to ø100)	Zinc chromating
	Double knuckle jeint	Carbon steel (ø20 to ø32)	Nickel plating
		Cast iron (ø40 to ø100)	Zinc chromating
Accessories	Rod end	Carbon steel	Zinc plating
Accessories	Knuckle pin	Carbon steel	_
	Clevis pin	Carbon steel	_
	Divet breeket	Carbon steel (ø20 to ø63)	Nickel plating
	PIVOL Dracket	Cast iron (ø80, ø100)	Nickel plating
	Mounting bolt	Carbon steel	Nickel plating
	Retaining ring	Carbon tool steel	Phosphate coating

Theoretical Output

									Unit: N
Bore size	Rod size	Operating	Piston area			Operating pr	essure [MPa]		
D [mm]	d [mm]	direction	[mm ²]	0.2	0.3	0.4	0.5	0.6	0.7
20	0	OUT	314	62.8	94.2	125.6	157	188.4	219.8
20	0	IN	264	52.8	79.2	105.6	132	158.4	184.8
05	10	OUT	491	98.2	147.3	196.4	245.5	294.6	343.7
25	10	IN	412	82.4	123.6	164.8	206	247.2	288.4
20	10	OUT	804	160.8	241.2	321.6	402	482.4	562.8
32	12	IN	691	138.2	207.3	276.4	345.5	414.6	483.7
40	14	OUT	1257	251.4	377.1	502.8	628.5	754.2	879.9
40	14	IN	1103	220.6	330.9	441.2	551.5	661.8	772.1
50	10	OUT	1964	392.8	589.2	785.6	982	1178.4	1374.8
50	10	IN	1709	341.8	512.7	683.6	854.5	1025.4	1196.3
62	10	OUT	3117	623.4	935.1	1246.8	1558.5	1870.2	2181.9
03	10	IN	2863	572.6	858.9	1145.2	1431.5	1717.8	2004.1
90	20	OUT	5027	1005.4	1508.1	2010.8	2513.5	3016.2	3518.9
80	22	IN	4646	929.2	1393.8	1858.4	2323	2787.6	3252.2
100	26	OUT	7854	1570.8	2356.2	3141.6	3927	4712.4	5497.8
100	20	IN	7323	1464.6	2196.9	2929.2	3661.5	4393.8	5126.1

Weight

									[kg]
Bore size [mm]		20	25	32	40	50	63	80	100
Desia	Basic	0.09	0.14	0.20	0.32	0.66	0.92	1.75	2.74
Basic	Long male rod end (G)	0.10	0.15	0.21	0.34	0.70	0.97	1.84	2.85
weight	Female rod end (F)	0.08	0.12	0.19	0.29	0.60	0.85	1.61	2.53
Additional	Foot bracket	0.11	0.13	0.16	0.22	0.48	0.72	0.96	1.75
weight for	Flange	0.08	0.10	0.14	0.20	0.34	0.50	0.71	1.35
bracket	Clevis	0.05	0.08	0.15	0.23	0.40	0.68	0.71	1.28
Pivot brack	et	0.08	0.09	0.17	0.25	0.44	0.80	0.98	1.75
Single knuc	kle joint	0.05	0.09	0.09	0.10	0.22	0.22	0.39	0.57
Double knuckle joint (with pin)		0.05	0.09	0.09	0.13	0.26	0.26	0.64	1.31
Additional weight per 50 mm of stroke		0.05	0.07	0.09	0.13	0.19	0.23	0.31	0.43
Additional v	veight for switch magnet	0.01	0.01	0.01	0.01	0.01	0.02	0.02	0.04

Calculation: (Example) CDG3FN20-100Z1 (Built-in magnet, Flange type, ø20, 100 mm stroke)

• Basic weight 0.09 (Basic type, ø20)

Additional weight for bracket 0.08 (Flange)

Additional weight for stroke 0.05/50 mm

• Air cylinder stroke 100 mm

• Additional weight for switch magnet ···· 0.01

0.09 + 0.08 + 0.05 x (100/50) + 0.01 = 0.28 kg

Allowable Kinetic Energy

Table (1) Max. Allowable Kinetic Energy										
Bore size [mm]	20	25	32	40	50	63	80	100		
Male rod end	0.2	0.29	0.46	0.84	1.4	2.38	4.13	6.93		
Female rod end 0.11 0.18 0.29 0.52 0.91 1.54 2.71 4										

Kinatia a	(m1	+ m2)	V ²
Kinetic e		2	

m1: Mass of cylinder movable parts kgm2: Load masskgV : Piston speed at the end m/s

Table (2) Mass of Cylinder Movable Parts: At Each Rod End/Without Built-in Magnet/0 Stroke [a]

					•			101
Bore size [mm]	20	25	32	40	50	63	80	100
Basic	30	54	74	121	254	297	603	935
Long male rod end (G)	36	64	89	146	300	343	683	1047
Female rod end (F)	23	40	62	91	184	226	462	728

 Mass of the rod end nut is included for the basic type and the long male rod end type (G).

Table (3) Additional Mass

/								101
Bore size [mm]	20	25	32	40	50	63	80	100
Additional mass per 50 mm of stroke	20	31	44	61	99	99	148	207
Switch magnet	4	4	9	13	14	22	24	35

* Do not apply a lateral load over the allowable range to the rod end when it is mounted horizontally.

Calculation: (Example) CDG3BN40-150Z1

 Standard mass of movable parts: Table (2) Rod end [Basic], Bore size [40]····121 g
 Additional mass: Additional mass of stroke 61 x 150/50 = 183 g ·····183 g Switch magnet ·····13 g

Total 317 g

[a]

Replacement Parts



Component Parts

No.	Description
1	Rod cover
2	Head cover
3	Cylinder tube
4	Piston rod assembly
5	Rod seal
6	Piston seal
7	Tube gasket

Replacement Parts: Seal Kit

Bore size [mm]	Kit no.	Contents								
20	CG3N20-PS									
25	CG3N25-PS	Sat of page (B) (A) (7)								
32	CG3N32-PS	Set of hos. (9, (0, ()								
40	CG3N40-PS									

 $\ast\,$ As sizes ø50 and larger cannot be disassembled, the seal cannot be replaced.

* Refer to the following for disassembly/replacement. Order with the kit number according to the bore size.

* The seal kit includes a grease pack (10 g). Order with the following part number when only the grease pack is needed. Grease pack part number: GR-S-010 (10 g)

Allowable Lateral Load at Rod End



Dimensions



[mm]				-			-						-	-					-	-	
20	14.5	12	13	14	8	12	2	7	6	20	5	4	26	M4 x 0.7 depth 7	3.5	6	M8 x 1.25	24	M5 x 0.8	57	79
25	17.5	15	17	16.5	10	14	2	9	7.5	23	6	4	31	M5 x 0.8 depth 7.5	3.5	8	M10 x 1.25	29	M5 x 0.8	60	85
32	17.5	15	17	20	12	18	2	7.5	7.5	23	6	4	38	M5 x 0.8 depth 8	3.5	10	M10 x 1.25	35.5	Rc1/8	62	87
40	23.5	20.5	19	26	14	25	2	7.5	7.5	29	8	5.5	47	M6 x 1 depth 10	3.5	12	M14 x 1.5	44	Rc1/8	62	93
50	29	26	27	32	18	30	2	12	12	35	11	8	58	M8 x 1.25 depth 16	4.5	16	M18 x 1.5	55	Rc1/4	84	121
63	29	26	27	38	18	32	2	12	12	35	11	8	72	M10 x 1.5 depth 16	4.5	16	M18 x 1.5	69	Rc1/4	84	121
80	35.5	32.5	32	50	22	40	3	17	12	44	13	9.5	89	M10 x 1.5 depth 22	4.5	19	M22 x 1.5	86	Rc1/4	104	151
100	35.5	32.5	41	60	26	50	3	15	15	44	16	9.5	110	M12 x 1.75 depth 22	4.5	22	M26 x 1.5	106	Rc3/8	105	152

*1 Long male rod end type (G) is the same rod end dimensions (A, AL, H) as the CG1 series.

* Use a thin wrench when tightening the piston rod.

* When a female thread is used, depending on the material of the workpiece, use a washer etc., to prevent the contact part at the rod end from being deformed.

Foot bracket: CG3LN Bore size - Stroke Z1





[mm]

Foot Bracket

*1 The rod end nut should be mounted in the position t (clearance) so that it will have a clearance of 1 mm or more in order to prevent interference of the nut with the bolt for mounting bracket when the rod is retracted.

Symbol Bore size	В	LC	LD	LH	LS	LT	LX	LZ	М	w	х	Y	z	ZZ
20	34	4	6	20	33	(3)	32	44	3	10	15	7	32	83
25	38.5	4	6	22	36	(3)	36	49	3.5	10	15	7	35	89.5
32	45	4	7	25	36	(3)	44	58	3.5	10	16	8	36	91.5
40	54.5	4	7	30	35	(3)	54	71	4	10	16.5	8.5	42.5	98
50	70.5	5	10	40	49	(4.5)	66	86	5	17.5	22	11	52.5	128.5
63	82.5	5	12	45	49	(4.5)	82	106	5	17.5	22	13	52.5	128.5
80	101	6	11	55	56	(4.5)	100	125	5	20	28.5	14	68	157.5
100	121	6	14	65	57	(6)	120	150	7	20	30	16	68	162

* Use a thin wrench when tightening the piston rod.

* Refer to the dimensions of the basic type for the female rod end type, the long male rod end type, and for other dimensions not shown above.



Dimensions







- *1 End boss is machined on the flange for øE.
- *2 The rod end nut should be mounted in the position t (clearance) so that it will have a clearance of 1 mm or more in order to prevent interference of the nut with the bolt for mounting bracket when the rod is retracted.

Rod Flange [mm]													
Symbol Bore size	В	E	FX	FD	FT								
20	40	12	28	5.5	6								
25	44	14	32	5.5	7								
32	53	18	38	6.6	7								
40	61	25	46	6.6	8								
50	76	30	58	9	9								
63	92	32	70	11	9								
80	104	40	82	11	11								
100	128	50	100	14	14								

 \ast Use a thin wrench when tightening the piston rod.

* Refer to the dimensions of the basic type for the female rod end type, the long male rod end type, and for other dimensions not shown above.

Head flange: CG3GN Bore size - Stroke Z1



Head Flange

Head Fla	ange						[mm]
Bore size [mm]	В	Е	F	FX	FD	FT	ZZ
20	40	12	2	28	5.5	6	85
25	44	14	2	32	5.5	7	92
32	53	18	2	38	6.6	7	94
40	61	25	2	46	6.6	8	101
50	76	30	2	58	9	9	130
63	92	32	2	70	11	9	130
80	104	40	3	82	11	11	162
100	128	50	3	100	14	14	166

* Use a thin wrench when tightening the piston rod.

* Refer to the dimensions of the basic type for the female rod end type, the long male rod end type, and for other dimensions not shown above.



*1 End boss is machined on the flange for øE.



Dimensions

Clevis: CG3DN Bore size - Stroke Z1 (Ø20 to Ø63)



Clevis (Ø20 to Ø63)

Bore size [mm]	CD	cz	L	RR	тт	ΤZ	z	zz	Applicable pin part no.
20	8	(29)	14	11	3.2	43.4	91	112	CD-G02
25	10	(33)	16	13	3.2	48	99	120	CD-G25
32	12	(40)	20	15	4.5	59.4	105	129	CD-G03
40	14	(49)	22	18	4.5	71.4	113	141	CD-G04
50	16	(60)	25	20	6	86	144	176	CD-G05
63	18	(74)	30	22	8	105.4	149	186	CD-G06



CX+0.5

CZ

ΤZ

* Use a thin wrench when tightening the piston rod.

* Refer to the dimensions of the basic type for the female rod end type, the long male rod end type, and for other dimensions not shown above.

[mm]

* Refer to page 8 for the pivot bracket.



Clevis	Clevis (ø80, ø100) [mm]														
Bore size [mm]	CD	сх	cz	L	RR	τz	v	z	zz	Applicable pin part no.					
80	18	28	56	35	18	64	26	183	241.5	IY-G08					
100	22	32	64	43	22	72	32	192	268.5	IY-G10					

* Use a thin wrench when tightening the piston rod.

* Refer to the dimensions of the basic type for the female rod end type, the long male rod end type, and for other dimensions not shown above.

* Refer to page 8 for the pivot bracket.



CG3 Series **Dimensions of Accessories**

[mm]

Single Knuckle Joint

I-GO2, I Material: (-G03 Carbon ste M ØN PR	eel DH10	 ↓ ↓↓]	L	I-G04, I-G05, I-G08, I-G10 Material: Cast iron								
Part no.	Applicable bore size [mm]	Α	A 1	E1	L1	ММ	R1	U1	ND H10	NX				
I-G02	20	34	8.5	□16	25	M8 x 1.25	10.3	11.5	8 +0.058	8 -0.2				
I-G03	25, 32	41	10.5	□20	30	M10 x 1.25	12.8	14	10 +0.058	10 -0.2				
I-G04	40	42	14	ø22	30	M14 x 1.5	12	14	10 ^{+0.058}	18 ^{-0.3}				
I-G05	50, 63	56	18	ø28	40	M18 x 1.5	16	20	14 ^{+0.070}	22 -0.3				
I-G08	80	71	21	ø38	50	M22 x 1.5	21	27	18 ^{+0.070}	$28^{-0.3}_{-0.5}$				
I-G10	100	79	21	ø44	55	M26 x 1.5	24	31	22 +0.084	$32^{-0.3}_{-0.5}$				

Knuckle Pin

Material: Carbon steel



Part no.	Applicable bore size [mm]	Dd9	L	d	L1	m	t	Included retaining ring			
IY-G02	20	8 -0.040 -0.076	21	7.6	16.2	1.5	0.9	Type C8 for axis			
IY-G03	25, 32	10 -0.040 -0.076	25.6	9.6	20.2	1.55	1.15	Type C10 for axis			
IY-G04	40	10 -0.040 -0.076	41.6	9.6	36.2	1.55	1.15	Type C10 for axis			
IY-G05	50, 63	$14_{-0.093}^{-0.050}$	50.6	13.4	44.2	2.05	1.15	Type C14 for axis			
IY-G08	80	18 -0.050 -0.093	64	17	56.2	2.55	1.35	Type C18 for axis			
IY-G10	100	22 -0.065	72	21	64.2	2.55	1.35	Type C22 for axis			

* Retaining rings are included.

Clevis Pin

Μ

Material: Carbon steel								
Part no.	Applicable bore size [mm]	Dd9	L	d	L1	m	t	Included retaining ring
CD-G02	20	8-0.040	43.4	7.6	38.6	1.5	0.9	Type C8 for axis
CD-G25	25	$10^{-0.040}_{-0.076}$	48	9.6	42.6	1.55	1.15	Type C10 for axis
CD-G03	32	12 -0.050	59.4	11.5	54	1.55	1.15	Type C12 for axis
CD-G04	40	14 -0.050	71.4	13.4	65	2.05	1.15	Type C14 for axis
CD-G05	50	16 -0.050 -0.093	86	15.2	79.6	2.05	1.15	Type C16 for axis
CD-G06	63	18-0.050	105.4	17	97.8	2.45	1.35	Type C18 for axis

Retaining rings are included.

* A clevis pin and a knuckle pin are common for the bore size ø80 and ø100.

Rod End Nut (For Male Thread)

Material: Carbon steel								
Part no.	Applicable bore size [mm]	d	H1	H2	B1	С	øD	øA
NT-02G3	20	M8 x 1.25	5	4	13	(15)	12.5	10
NT-03G3	25, 32	M10 x 1.25	6	4	17	(19.6)	16.5	12
NT-04G3	40	M14 x 1.5	8	5.5	19	(21.9)	18	16.4
NT-05G3	50, 63	M18 x 1.5	11	8	27	(31.2)	26	20.4
NT-08G3	80	M22 x 1.5	13	9.5	32	(37)	31	28
NT-10G3	100	M26 x 1.5	16	9.5	41	(47.3)	39	33

Double Knuckle Joint



Y-G10 100 79 24 ø44 55 M26 x 1.5 24 31 * A knuckle pin and retaining rings are included.

Pivot Bracket (Order separately)





Auto Switch Mounting Position (From the end of the cover)

Bore size	D-M9 D-M9 D-M9	9□(V) □W(V) □A(V)	D-AS	9□(V)	D-C D-G D-H D-K D-G D-G D-G	35 5 5 59 59 359 5 5 8 5 8 5 8 5 8 5 8 5 8 5 8 7	D-E D-I	35⊡ 364	D-B	59W
	A	В	A	В	A	В	A	В	Α	В
20	23.5	21.5	19.5	17.5	15.5	13.5	14	13	17	15
25	24.5	23.5	20.5	19.5	16.5	15.5	15	15	18	17
32	25	25	21	21	17	17	15.5	15.5	18.5	18.5
40	25	25	21	21	17	17	15.5	15.5	18.5	18
50	36.5	35.5	32.5	31.5	28.5	27.5	27	26	30	29
63	36.5	35.5	32.5	31.5	28.5	27.5	27	26	30	29
80	_	—	—	_	39	37	37.5	35.5	40.5	38.5
100	—	—	_	_	39.5	37.5	38	36	41	39

	D-M9□(V) D-M9□W(V) D-M9□A(V) D-A9□(V)	D-K59W D-K59W D-G59F D-G5BA D-G5NT D-B5□ D-B50 D-B64 D-B59W		
Bore size	Hs	Hs		
20	26.5	27.5		
25	29	30		
32	32.5	33.5		
40	37	38		
50	42.5	43.5		
63	49.5	50.5		
80	—	59		
100	—	69.5		

Auto Switch Mounting CG3 Series

				n: Numb	er of auto switches [mm]			
	Number of auto switches							
Auto switch model	With 1 pc	With	2 pcs.	With	n pcs.			
	with tipe.	Different surfaces	Same surface	Different surfaces	Same surface			
D-M9□	5	15* ¹	40*1	$20 + 35 \frac{(n-2)}{2}$ (n = 2, 4, 6···)* ³	55 + 35 (n - 2) (n = 2, 3, 4, 5…)			
D-M9⊡W	10	15 ^{*1}	40*1	$20 + 35 \frac{(n-2)}{2}$ $(n = 2, 4, 6\cdots)^{*3}$	55 + 35 (n – 2) (n = 2, 3, 4, 5…)			
D-M9⊡A	10	25	40*1	$25 + 35 \frac{(n-2)}{2} \\ (n = 2, 4, 6 \cdots)^{*3}$	60 + 35 (n - 2) (n = 2, 3, 4, 5…)			
D-A9□	5	15	30* ¹	$15 + 35 \frac{(n-2)}{2}$ $(n = 2, 4, 6\cdots)^{*3}$	50 + 35 (n - 2) (n = 2, 3, 4, 5…)			
D-M9⊡V	5	20	35	$20 + 35 \frac{(n-2)}{2}$ $(n = 2, 4, 6 \cdots)^{*3}$	35 + 35 (n – 2) (n = 2, 3, 4, 5…)			
D-A9⊡V	5	15	25	$15 + 35 \frac{(n-2)}{2}$ (n = 2, 4, 6···)* ³	25 + 35 (n - 2) (n = 2, 3, 4, 5…)			
D-M9⊟WV D-M9⊟AV	10	20	35	$20 + 35 \frac{(n-2)}{2}$ $(n = 2, 4, 6 \cdots)^{*3}$	35 + 35 (n – 2) (n = 2, 3, 4, 5…)			
D-G5□ D-G5□W D-K59 D-K59W D-G59F D-G5BA D-G5NT D-B5□ D-B64	5	20	75	$20 + 50 \frac{(n-2)}{2}$ (n = 2, 4, 6···)*3	75 + 55 (n – 2) (n = 2, 3, 4, 5…)			
D-B59W	10	20	70	$20 + 50 \frac{(n-2)}{2}$ $(n = 2, 4, 6 \cdots)^{*3}$	70 + 50 (n – 2) (n = 2, 3, 4, 5…)			

Minimum Stroke for Auto Switch Mounting

*3 When "n" is an odd number, an even number that is one larger than the odd number is to be used for the calculation.

*1 Auto switch mounting

	With 2 aut	o switches
	Different surfaces	Same surface
Auto switch model		
	Correct auto switch mounting position is 3.5 mm from the back face of the switch holder.	The auto switch is mounted by slightly displacing it in a direction (cylinder tube circumferential exterior) so that the auto switch and lead wire do not interfere with each other.
D-M9□ D-M9□W	Less than 20 mm stroke ^{*2}	Less than 55 mm stroke ^{*2}
D-M9⊡A	Less than 20 mm stroke ^{*2}	Less than 60 mm stroke ^{*2}
D-A9	_	Less than 50 mm stroke ^{*2}

*2 Minimum stroke for auto switch mounting in types other than those mentioned in *1

Auto Switch Mounting Brackets/Part Nos.



- *1 Since the switch bracket (made of polyamide) is affected in an environment where chemicals are splashed over, so it cannot be used. (Especially alcohol, chloroform, methylamine, hydrochloric acid, sulfuric acid, etc.)
- *2 When mounting a D-M9 \square A(V) type auto switch, if the switch bracket is mounted on the indicator light, it may damage the auto switch. Therefore, be sure to avoid mounting the switch bracket on the indicator light.

Band Mounting Brackets Set Part Nos.

Set part no.	Contents
BJ4-1	 Switch bracket (White/PBT) (e) Switch holder (b)
BJ5-1	 Switch bracket (Transparent/Polyamide) (a) Switch holder (b)

Operating Range

								[mm]	
Auto owitch model		Bore size							
Auto switch model	20	25	32	40	50	63	80	100	
D-M9□(V) D-M9□W(V) D-M9□A(V)	4.5	5.0	4.5	5.5	5.0	5.5	_	_	
D-A9□(V)	7	6	8	8	8	9	-	_	
D-G5□/G5□W/K59 D-K59W/G59F D-G5BA/G5NT	4	4	4.5	5	6	6.5	6.5	7	
D-B5□/B64	8	10	9	10	10	11	11	11	
D-B59W	13	13	14	14	14	17	16	18	

 Values which include hysteresis are for reference purposes only. They are not a guarantee (assuming approx. ±30% dispersion) and may change substantially depending on the ambient environment.

Cylinder Mounting Bracket, by Stroke/Auto Switch Mounting Surfaces

			st: Stroke [mm]					
	Basic, Fo	Basic, Foot bracket, Flange, Clevis						
Auto switch model	With 1 pc. With 2 pcs.		With 2 pcs.					
	(Roa cover side)	(Different surfaces)	(Same surface)					
Switch mounting								
surface	Port surface	Port surface	Port surface					
Switch model			ļ					
D-M9□(V) D-M9□W(V) D-M9□A(V) D-A9□(V)	10 st or more	15 to 44 st	45 st or more					
D-G5□/G5□W/K59 D-K59W/G59F D-G5BA/G5NT D-B5□/B64	10 st or more	15 to 74 st	75 st or more					
D-B59W	15 st or more	20 to 74 st	75 st or more					

CG3 Series D-H7, D-C7/C8 Auto Switch Mounting

Other than the applicable auto switches listed in "How to Order," the following auto switches are also mountable. Refer to the Web Catalog for detailed specifications. Туре Model Electrical entry Features Applicable bore size L D-H7A1, H7A2, H7B D-H7NW, H7PW, H7BW Diagnostic indication (2-color indicator) ø20 to ø63 Solid state D-H7NF Grommet (In-line) With diagnostic output (2-color indicator) L D-H7BA Water resistant (2-color indicator) D-G5NT With timer ø20 to ø100 D-C73, C76, B53 ø20 to ø63 D-C80 Without indicator light Reed Grommet (In-line) D-B59W Diagnostic indication (2-color indicator) ø20 to ø100 With pre-wired connector is also available for solid state auto switches. For details, refer to the Web Catalog Normally closed (NC = b contact) solid state auto switches (D-M9 E(V)) are also available. For details, refer to the Web Catalog

Auto Switch Proper Mounting Position (Detection at stroke end) and Mounting Height

Solid state auto switch

D-H7□, H7□W D-H7NF, H7BA ø20 to ø63



Reed auto switch

D-C7□, C80 ø20 to ø63



Auto Switch Mounting Position (From the end of the cover) [mm]

Bore size	D-H D-H D-H D-H	17□ 7□W 7NF 7BA	D-C7⊡ D-C80		
	A	В	A	В	
20	19	17	20	18	
25	20	19	21	20	
32	20.5	20.5	21.5	21.5	
40	20.5	20.5	21.5	21.5	
50	32	31	33	32	
63	32	31	33	32	

Auto Switch Mounting Height [mm]

Auto switch model	D-H7□ D-H7□W D-H7NF D-H7BA D-C7□ D-C80
Bore size	Hs
20	26.5
25	29
32	32.5
40	37
50	42.5
63	49.5

Minimum Stroke for Auto Switch Mounting

				n: Numb	er of auto switches [mm]			
	Number of auto switches							
Auto switch model	With 1 pp	With	2 pcs.	With n pcs.				
	with 1 pc.	Different surfaces	Same surface	Different surfaces	Same surface			
D-H7□ D-H7□W D-H7NF D-H7BA	10	25	70	$25 + 45 \frac{(n-2)}{2}$ (n = 2, 4, 6)*1	70 + 45 (n – 2) (n = 2, 3, 4, 5…)			
D-C7⊡ D-C80	5	20	60	$20 + 45 \frac{(n-2)}{2}$ (n = 2, 4, 6···)*1	60 + 45 (n – 2) (n = 2, 3, 4, 5…)			

*1 When "n" is an odd number, an even number that is one larger than the odd number is to be used for the calculation.

Operating Range

						[mm]
Auto owitch model	Bore size					
Auto switch model	20	25	32	40	50	63
D-H7□/H7□W D-H7NF/H7BA	4	4	4.5	5	6	6.5
D-C7□/C80	8	10	9	10	10	11

* Values which include hysteresis are for reference purposes only. They are not a guarantee (assuming approx. ±30% dispersion) and may change substantially depending on the ambient environment.

Cylinder Mounting Bracket, by Stroke/Auto Switch Mounting Surfaces

			st: Stroke [mm]		
	Basic, Foot bracket, Flange, Clevis				
Auto switch model	With 1 pc. (Rod cover side)	With 2 pcs. (Different surfaces)	With 2 pcs. (Same surface)		
Switch mounting surface	Port surface	Port surface	Port surface		
Switch model					
D-H7□/H7□W D-H7NF/H7BA	10 st or more	15 to 59 st	60 st or more		
D-C7□/C80	10 st or more	15 to 49 st	50 st or more		



CG3 Series Specific Product Precautions

Be sure to read this before handling the products. Refer to the back cover for safety instructions. For actuator and auto switch precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual" on the SMC website: https://www.smcworld.com

Handling

MWarning

- 1. The allowable kinetic energy is different between the cylinders with male rod end and with female rod end due to the different thread sizes. Refer to page 4.
- 2. When the cylinder is used as mounted with a single side fixed or free (basic type, flange type), be careful not to apply vibration or impact to the cylinder body. A bending moment will be applied to the cylinder due to the vibration generated at the stroke end, and the cylinder may be damaged. In such a case, mount a bracket to reduce the vibration of the cylinder or use the cylinder at a piston speed low enough to prevent the cylinder from vibrating at the stroke end.

Furthermore, when the cylinder is moved or mounted horizontally and with a single side fixed, use a bracket to fix the cylinder.

3. When female rod end is used, use a washer, etc., to prevent the contact part at the rod end from being deformed depending on the material of the workpiece.



These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution," "Warning" or "Danger." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)*1), and other safety regulations.

н

Danger : Danger indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury. Marning: Warning indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.

Caution indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.

A Warning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalog information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

- 3. Do not service or attempt to remove product and machinery/ equipment until safety is confirmed.
 - 1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
 - 2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
 - 3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.
- 4. SMC products cannot be used beyond their specifications. They are not developed, designed, and manufactured to be used under the following conditions or environments. Use under such conditions or environments is not allowed.
 - 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
 - 2. Use for nuclear power, railways, aviation, space equipment, ships, vehicles, military application, equipment affecting human life, body, and property, combustion equipment, entertainment equipment, emergency shut-off circuits, press clutches, brake circuits, safety equipment, etc., and use for applications that do not conform to standard specifications such as catalogs and operation manuals.
 - 3. Use for interlock circuits, except for use with double interlock such as installing a mechanical protection function in case of failure. Please periodically inspect the product to confirm that the product is operating properly.

*1) ISO 4414: Pneumatic fluid power - General rules and safety requirements for systems and their components ISO 4413: Hydraulic fluid power - General rules and safety requirements for systems and their components IEC 60204-1: Safety of machinery - Electrical equipment of machines - Part 1: General requirements ISO 10218-1: Robots and robotic devices - Safety requirements for industrial robots - Part 1: Robots etc.

SMC develops, designs, and manufactures products to be used for automatic control equipment, and provides them for peaceful use in manufacturing industries.

Use in non-manufacturing industries is not allowed.

Products SMC manufactures and sells cannot be used for the purpose of transactions or certification specified in the Measurement Act of each country. The new Measurement Act prohibits use of any unit other than SI units in Japan.

Limited warranty and Disclaimer/ Compliance Requirements

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".

Read and accept them before using the product.

Limited warranty and Disclaimer

- 1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first.*2) Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
- 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- 3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalog for the particular products.
 - *2) Suction cups (Vacuum pads) are excluded from this 1 year warranty. A suction cup (vacuum pad) is a consumable part, so it is warranted for a year after it is delivered.

Also, even within the warranty period, the wear of a product due to the use of the suction cup (vacuum pad) or failure due to the deterioration of rubber material are not allowed by the limited warranty.

Compliance Requirements

- 1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- 2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

A Safety Instructions Be sure to read the "Handling Precautions for SMC Products" (M-E03-3) and "Operation Manual" before use.

SMC Corporation https://www.smcworld.com

Specifications are subject to change without prior notice and any obligation on the part of the manufacturer. © 2025 SMC Corporation All Rights Reserved