
# **Rotary Table/Rack & Pinion Type**

MSQ Series

Size: 1, 2, 3, 7, 10, 20, 30, 50, 70, 100, 200



# **Compact Rotary Table with Low Table Height**






# Small sizes 1, 2, 3, and 7



# Variety of installation options for space saving

Offers maximum space saving installation by taking advantage of the compact body, space saving wiring and piping.



# **External shock absorber types**

# 4 to 10 times more allowable kinetic energy (Compared with internal shock absorber type)

2 types of shock absorbers are available, for low energy and

Allowable kinetic energy comparison (for size 30)

With external shock absorber

For high energy

0.01

With internal shock absorber

With adjustment bolt

0.0001

0.0001

0.0001

Rotation time (s/90°)

### Total length shortened

Longitudinal mounting space is reduced because there is no protrusion from adjustment bolts or internal shock absorbers






Table height is the same for both types with adjustment bolts or internal shock absorber


# 90°, 180°

Rotation angle:


Left / Right symmetric type





### Table Displacement (Reference values)




### **Table Displacement (Reference values)**










### Rotation Accuracy: Displacement Values at 180° (Reference values)




		mm
Measuring plate	MSQA	MSQB
Rotating amount of table top	0.03	0.1
Rotating amount of table side	0.03	0.1

Values in the table are actual values and not guaranteed values.

# **Rotary Table/Rack & Pinion Type** MSQ Series

Size: 1, 2, 3, 7

### **How to Order**



The port location cannot be changed after the delivery of the product.

### Applicable Auto Switches/Refer to pages 929 to 983 for detailed auto switch specification.

		F1	ō	Wiring	L	oad voltag	je	Auto swit	ch model	Lead v	vire le	ngth (r	n)*																					
Туре	Special function	Electrical entry	Indicator light	(Output)		DC	AC	Perpendicular	In-line	0.5 (Nil)	1 (M)	3 (L)	5 (Z)	Pre-wired connector	Applica	ble load																		
				3-wire (NPN)		5 V, 12 V		M9NV	M9N	•	•	•	0	0																				
				3-wile (IVI IV)			5 V, 12 V	5 V, 12 V		F8N	_	•	_	•	0	_	l ic																	
				3-wire (PNP)					5 V, 12 V	5 V, 12 V	5 V, 12 V	5 V, 12 V		M9PV	M9P	•	•	•	0	0	circuit													
switch	_			3-wile (FINE)									F8P	_	•	_	•	0	_															
NS C				2-wire		12 V		12.1/		M9BV	M9B	•	•	•	0	0																		
auto		Grommet	Yes	2-wire	24 V				F8B	_	•	_	•	0	_	_	Relay,																	
state		Gioiiiiiei	165	3-wire (NPN)		5 V, 12 V							5 V 40 V			_	M9NWV	M9NW	•	•	•	0	0	IC	PLC									
	Diagnostic indication (2-color indicator)			3-wire (PNP)									5 V, 12 V	5 V, 12 V	5 V, 12 V								5	5 V, 12 V	5 V, 12 V	5 V, 12 V	J V, 12 V	5 4, 12 4	5 V, 12 V	J V, 12 V	5 V, 12 V	5 V, 12 V	5 V, 12 V	
Solid	(2-color indicator)			2-wire		12 V	12 V	12 V		M9BWV	M9BW	•	•	•	0	0	_																	
				3-wire (NPN)	5 V 4		5 V	5.V. 40.V	5 1/ 40 1/	5 V 40 V	5 1/ 40 1/	5 1/ 40 1/	5 1/ 40 1/	5 1/ 40 1/		M9NAV**	M9NA**	0	0	•	0	0	IC											
	Water resistant (2-color indicator)			3-wire (PNP)		5 V, 12 V	5 V, 12 V		M9PAV**	M9PA**	0	0	•	0	0	circuit																		
	(= 10.0. maioator)			2-wire		12 V		M9BAV**	M9BA**	0	0	•	0	0	_																			

- \*\* Although it is possible to mount water resistant type auto switches, note that the rotary actuator itself is not of water resistant construction.
- \* Auto switches marked with "O" are made to order specification. \* Lead wire length symbols: 0.5 m ····· Nil (Example) M9NW
  - 1 m ····· M (Example) M9NWM
  - 3 m ····· L (Example) M9NWL
- \* Refer to pages 970 and 971 for the details of solid

state auto switch with pre-wired connector. 5 m ····· Z (Example) M9NWZ

Note 1) When using D-F8□, mount it at a distance of 10 mm or more from magnetic substances such as iron.

<sup>\*</sup> Auto switches are shipped together, (but not assembled).

# Rotary Table/Rack & Pinion Type **MSQ** Series



Basic type



High precision type

### Symbol



### **Specifications**

		_	_	7					
Size	1 2 3								
Fluid	Air (non-lube)								
Maximum operating pressure	0.7 MPa								
Minimum operating pressure	0.1 MPa								
Ambient and fluid temperature	0 to 60°C (with no freezing)								
Cushion	None	•	Rubber I	oumper					
Angle adjustment range		0 to	190°						
Maximum rotation		19	0°						
Cylinder bore size	ø6 ø8 ø10 ø12								
Port size	M3 x 0.5 M5 x 0.8								

### Allowable Kinetic Energy and Rotation Time Adjustment Range

Size	Allowable kinetic energy (J)	Rotation time adjustment range for suitable operation (s/90°)
1	0.001	
2	0.0015	0.2 to 0.7
3	0.002	
7	0.006	0.2 to 1.0

Note) If operated where the kinetic energy exceeds the allowable value, this may cause damage to the internal parts and result in product failure. Please pay special attention to the kinetic energy levels when designing and during operation to avoid exceeding the allowable limit.

### Weight


				(g)
Size	1	2	3	7
Basic type	75	105	150	250
High precision type	80	115	165	265

Note) Excluding the weight of auto switches

### **Clean Series**

Prevents dispersion of the particles generated inside of the product into the clean room by sucking them out of the vacuum port on the body side.

### How to Order



### **Specifications**


Cleanliness class (ISO class)	Suction flow rate (example)
Class 3 Note 1)	1 L/min (ANR)

11-MSQA is identical to the high precision type and 11-MSQB is identical to the basic type.

Note 1) Please refer to the Web Catalog for further details.

### **Dimensions**

Clean series products do not have a hollow axis.






Size	BK	PA
1	5.3	M3 x 0.5
2	7.5	M3 x 0.5
3	9.5	M3 x 0.5
7	7	M5 x 0.8

Dimensions other than above are identical to the basic type and the high precision type.

### **Rotation Direction and Rotation Angle**

- The rotary table turns in the clockwise direction when the A port is pressurized, and in the counter-clockwise direction when the B port is pressurized.
- By adjusting the adjustment bolt, the rotation end can be set within the range shown in the drawing.



With adjustment bolt, internal shock absorber


Size	Adjustment angle per rotation of angle adjustment screw
1	8.2°
2	10.0°
3	10.9°
7	10.2°

Note) • The drawing shows the rotation range of the positioning pin hole.


. The pin hole position in the drawing shows the counter-clockwise rotation end when the adjustment bolts A and B are tightened equally and the rotation is adjusted 180°.


### **Rotation Range Example**

• Various rotation ranges are possible as shown in the drawings below using adjustment bolts A and B. (The drawings also show the rotation ranges of the positioning pin hole.)




### Construction









Component Parts

COII	ipolielii rai is					
No.	Descri	ption		Material	Note	
1	Body			Aluminium alloy	Anodized	
2	Cover			Aluminium alloy	Anodized	
3	Plate		Aluminium alloy	Chromated		
4	Seal		NBR			
5	End cover			Aluminium alloy	Anodized	
6	Piston			Stainless steel		
7	Pinion			Chrome molybdenum steel		
8	Hexagon nut		Steel wire			
9	Adjustment bolt		Steel wire			
10	Cushion pad	Size: 3, 7		Rubber material		
11	Table			Aluminium alloy	Anodized	
12	Bearing retainer		Aluminium alloy	Anodized		
13	Magnet		_			
14	Wear ring		Resin			
15	Piston seal			NBR		
16	Deep groove ball bearing	J		Bearing steel		
17	Deep groove ball bearing	Basic type		Bearing steel		
17	Special bearing	High precisio	n type	Bearing steel		
	Round head Philips screw No.0	Basic type	Size: 1 to 3			
18	Round head Philips screw	basic type	Size: 7	Steel wire		
	Round head Philips screw	High precisio	n type			
19	Round head Philips scre	w No.0		Steel wire		
20	Hexagon socket head set bolt			Stainless steel		
21	Parallel pin			Carbon steel		
22	Seal washer	_		NBR		
23	Hexagon socket head se	t screw		Stainless steel		
24	O-ring			NBR		


<sup>\*23</sup> The hexagon socket head set screws are tightened at different positions depending on the position of the connecting port.

\* The component parts cannot be shipped individually.

\* Not able to disassemble. Refer to page 362 for details.




### Dimensions/Size 1, 2, 3, 7



# Rotary Table/Rack & Pinion Type **MSQ Series**

Size: 10, 20, 30, 50, 70, 100, 200

### **How to Order**



#### \* Refer to the table below for auto switch types.

#### Applicable Auto Switches/Refer to pages 929 to 983 for detailed auto switch specification.

744	ilicable Auto Swi	COLICOVIN	eiei t	pages 323 io	303 101	uetalleu at	ILO SWILCIT	specification														
on.		Et a de cart	ō	140		Load volta	ge	Auto swit	ch model	Lead wire length		(m) D										
Туре	Special function	Electrical entry	Indicator light	Wiring (Output)	ı	DC		Perpendicular	In-line	0.5 (Nil)	1 (M)	3 (L)	5	Pre-wired connector	Applical	ole load						
				3-wire (NPN)		5 V. 12 V		M9NV	M9N	•	•	•	0	0	IC							
switch	_			3-wire (PNP)		5 V, 12 V		M9PV	M9P	•	•	•	0	0	circuit							
SW				2-wire	wire (NPN) wire (PNP) 24 V	12 V	1	M9BV	M9B	•	•	•	0	0	_							
anto	Diamontic indication	1		3-wire (NPN)		-l 15 V 12 VI	24 V	24 V	24 V		l	E V 10 V	]	M9NWV	M9NW	•	•	•	0	0	IC	
	Diagnostic indication (2-color indicator)	Grommet	Yes	3-wire (PNP)						_	M9PWV	M9PW	•	•	•	0	0	circuit	Relay, PLC			
state	(E color malcator)			2-wire				12 V	1	M9BWV	M9BW	•	•	•	0	0	_	' - 0				
olid s	14/-1	1		3-wire (NPN)	5 V. 12 V		1	M9NAV*1	M9NA*1	0	0	•	0	0	IC							
Sol	Water resistant (2-color indicator)			3-wire (PNP)	5 V, 12	5 V, 12 V		M9PAV*1	M9PA*1	0	0	•	0	0	circuit							
	(2-color indicator)			2-wire		12 V	1	M9BAV*1	M9BA*1	0	0	•	0	0	_							
lo switch		Grommet	Yes	3-wire (NPN equiv.)	_	5 V	_	A96V	A96	•	•	•	•	0	IC circuit	_						
d auto	_	Gioinmet		0	04.1/	12 V	100 V	A93V	A93	•	•	•	•	0*2	_	Relay,						
Reed			No	2-wire	24 V	12 V	100 V or less	A90V	A90	•	•	•	•	0*2	IC circuit	PLC						

<sup>\*1</sup> Although it is possible to mount water resistant type auto switches, note that the rotary actuator itself is not of water resistant construction.



<sup>\*2</sup> The load voltage used is 24 VDC.

<sup>\*</sup> Lead wire length symbols: 0.5 m ······ Nil (Example) M9NW 1 m ····· M (Example) M9NWM

<sup>3</sup> m ····· L (Example) M9NWL 5 m ···· Z (Example) M9NWZ

<sup>\*</sup> Auto switches are shipped together, (but not assembled).

<sup>\*</sup> Auto switches marked with a "O" are produced upon receipt of orders.

<sup>\*</sup> Refer to the Web Catalog for the details of auto switch with pre-wired connector.



Basic type/MSQB

### Symbol



### **Specifications**


0:			40	-00	00		70	400	000			
Size			10	20	30	50	70	100	200			
Fluid			Air (non-lube)									
Maximum operating	With	adjustment bolt		1 MPa								
pressure	With in	iternal shock absorber		0.6 MPa Note 1)								
Minimum operating	Basi	c type				0.1 MPa						
pressure	High	precision type	0.2 MPa	_	0.1 MPa		_					
Ambient and	d fluid	d temperature			0 to 60°0	freezing)						
	With	adjustment bolt	Rubber bumper									
Cushion	With in	iternal shock absorber	Shock absorber									
		Shock absorber model	RBA0805 -X692	RBA100	06-X692	RBA1411 -X692		15-X821	RBA2725 -X821			
Angle adju	ıstm	ent range	0 to 190° Note 2)									
Maximum	rota	tion	190°									
Cylinder b	ore	size	ø15	ø18	ø21	ø25	ø28	ø32	ø40			
Port size	Enc	l ports	M5 >	¢ 0.8		Rc 1/8,	G 1/8, NP	T 1/8				
PUIT SIZE	Sid	e ports		M5 x 0.8								

Note 1) The maximum operating pressure of the actuator is restricted by the maximum allowable thrust of the shock absorber.

Note 2) Be careful if the rotation angle of a type with internal shock absorber is set below the value in the table below, the piston stroke will be smaller than the shock absorber's effective stroke, resulting in decreased energy absorption ability.

Size	10	20	30	50	70	100	200
Minimum rotation angle that will not allow decrease of energy absorption ability	52°	43°	40°	60°	71°	62°	82°

The service life of the shock absorber may be different from the rotary table body depending on the operating conditions. Refer to Specific Product Precautions for the suitable replacement period.



### Allowable Kinetic Energy and Rotation Time Adjustment Range

	Allowable kinet	tic energy (J) Note 1)	Rotation time adjustment ran					
Size	With adjustment bolt	With internal shock absorber	With adjustment bolt	With Note 2) internal shock absorber				
10	0.007	0.039						
20	0.025	0.116	001-40	004-07				
30	0.048	0.116	0.2 to 1.0	0.2 to 0.7				
50	0.081	0.294						
70	0.240	1.100	0.2 to 1.5					
100	0.320	1.600	0.2 to 2.0	0.2 to 1.0				
200	0.560	2.900	0.2 to 2.5					

Note 1) If operated where the kinetic energy exceeds the allowable value, this may cause damage to the internal parts and result in product failure. Please pay special attention to the kinetic energy levels when designing and during operation to avoid exceeding the allowable limit.

Note 2) When the rotation time of the type with an internal absorber is set longer than the time shown in the table above, energy absorption of the shock absorber greatly decreases.

### Weight


								(g)
	Size	10	20	30	50	70	100	200
Donie tumo	With adjustment bolt	500	940	1230	1990	2880	4090	7580
Basic type	With internal shock absorber	510	940	1230	2010	2890	4100	7650
High precision	With adjustment bolt	530	1040	1350	2150			
type	With internal shock absorber	540	1040	1350	2170			

Note) Values above do not include auto switch weight.



### **Rotation Direction and Rotation Angle**

- The rotary table turns in the clockwise direction where the A port is pressurized, and in the counter-clockwise direction when the B port is pressurized.
- By adjusting the adjustment bolt, the rotation end can be set within the ranges shown in the drawing.
- The rotation angle can also be set on a type with internal absorber.



Positioning pin hole

Adjustment bolt A

(For counter-clockwise rotation end adjustment)

Adjustment bolt B

(For clockwise rotation end adjustment)

Adjustment bolt B

(For clockwise rotation end adjustment)

Adjustment bolt B

(For clockwise rotation end adjustment)

Adjustment bolt A

(For clockwise rotation end adjustment)

Adjustment bolt A

(For clockwise rotation end adjustment)

Adjustment bolt A

(For clockwise rotation end adjustment)

Adjustment bolt B

(For clockwise rotation end adjustment)

With adjustment bolt, internal shock absorber


Size	Adjustment angle per rotation of angle adjustment screw
10	10.2°
20	7.2°
30	6.5°
50	8.2°
70	7.0°
100	6.1°
200	4.9°


Note) • The drawing shows the rotation range of the positioning pin hole.

 The pin hole position in the drawing shows the counter-clockwise rotation end when the adjustment bolts A and B are tightened equally and the rotation is adjusted 180°.

### **Rotation Range Example**

- Various rotation ranges are possible as shown in the drawings below using adjustment bolts A and B. (The drawings also show the rotation ranges of the positioning pin hole.)
- The rotation angle can also be set on a type with inertial absorber.






### **Clean Series**

Prevents dispersion of the particles generated inside of the product into the clean room by sucking them out of the vacuum port on the body side.

### **How to Order**



### Specifications

Cleanliness class (ISO class)	Suction flow rate (example)
Class 3 Note 1)	1 I /min (ANR)


11-MSQA is identical to the high precision type and 11-MSQB is identical to the basic type.

Note 1) Please refer to the Web Catalog for further details.



### **Dimensions**


Clean series products do not have a hollow axis.



							(mm)
Size	<b>DA</b> (h9)	<b>DB</b> (h9)	<b>DC</b> (H9)	<b>DD</b> (h9)	НВ	HC	HD
10	46	45	20	35	20	5	59
20	61	60	28	40	22	6	65
30	67	65	32	48	22	6	68
50	77	75	35	54	24	7	77

Dimensions other than above are identical to the basic type.


### High precision type



									(mm)
Size	<b>DA</b> (h8)	<b>DB</b> (h8)	<b>DC</b> (H8)	<b>DD</b> (h8)	HA	НВ	HC	HD	HE
10	46	45	20	35	15.5	24	5	63	9.5
20	61	60	28	40	19.5	30	6	73	13.5
30	67	65	32	48	19.5	30	6	76	13.5
50	77	75	35	54	21.5	34	7	87	15.5

Dimensions other than above are identical to the high precision type.

### Construction



### Parts list

No.	De	scription	on	Material	Note
1	Body			Aluminium alloy	Anodized
2	Cover	Clea	n Series	Aluminium alloy	Nickel plated
2	Cover	Exce	pt Clean Series	Aluminium alloy	Plated
3	Plate			Aluminium alloy	Chromated
4	Seal			NBR	
5	End cover	Clea	n Series	Aluminium alloy	Nickel plated
, o	Ella cover	Exce	pt Clean Series	Aluminium alloy	Plated
6	Piston			Stainless steel	
7	Pinion			Chrome molybdenum steel	
8	Compact hexago	n nut	Size: 10 to 50	Steel wire	
8	Hexagon nut		Size: 70 to 200	Steel wife	
9	Adjustment bolt			Chrome molybdenum steel	Chromated
10	Cushion pad			Rubber material	
11	_		Size: 10 to 50	_	
- 11	Seal retainer		Size: 70 to 200	Aluminium alloy	Chromated
12	Gasket			NBR	
13	Gasket			NBR	
14	Table			Aluminium alloy	Anodized
15	Bearing retainer			Aluminium alloy	Anodized
16	Magnet			_	
17	Wear ring			Resin	
18	Piston seal			NBR	

No.	Descrip	otion	Material	Note
	Bearing	Size: 10 to 50	Bearing steel	
19	Needle bearing	Size: 70 to 200	bearing steel	
20	Bearing	Basic type	Bearing steel	
20	Angular bearing	High precision type	Dearing steel	
21	Daniel band abilian array No O	Size: 20 to 50	Steel wire	
21	Round head philips screw No.0	Size: 70 to 200	Stainless steel	
	Round head philips screw	Size: 10	Steel wire	
22	Hexagon thin socket head bolt	Size: 20 to 50	Steel wire	
	Hexagon socket head set bolt	Size: 70 to 200	Steel wife	
23	Hexagon socket head	set bolt	Stainless steel	
24	Hexagon socket	Size: 10 to 70	Stainless steel	
24	head set bolt	Size: 100 to 200	Steel wire	
25	Bushing nut	Size: 10 to 50	Stainless steel	
25	Type CS retaining ring	Size: 70 to 200	Stairliess steel	
26	Parallel pin	Size: 10 to 50	Carbon steel	
26	Parallel key	Size: 70 to 200	Carbon steer	
27	Seal washer		NBR	
28	Plug		Steel wire	Nickel plated
29	O-ring	Size: 70 to 200 only	NBR	
30	Steel balls	Size: 70 to 200 only	Stainless steel	
31	Shock absorber		_	

### Replacement parts [Only replaceable for the MSQB]


· iopiaooi		int parto [	٠.	<u>y</u>	. opiaooai	•••	•			_											
Description											Size										
Description		10		Π	20			30			50			70			100			200	
Seal kit		P523010-5		Г	P523020-5			P523030-5			P523040-5		Г	P391050-5			P391060-5			P391070-5	
	No.	Description	Qty.	No	Description	Qty.	No	Description	Qty.	No.	Description	Qty.									
	4	Seal	1	4	Seal	1	4	Seal	1	4	Seal	1	4	Seal	1	4	Seal	1	4	Seal	1
Parts included	12	Gasket	1	12	Gasket	1	12	Gasket	1	12	Gasket	1	12	Gasket	4	12	Gasket	4	12	Gasket	4
in seal kit	13	Gasket	1	13	Gasket	1	13	Gasket	1	13	Gasket	1	17	Wear ring	4	17	Wear ring	4	17	Wear ring	4
III Sedi Kit	17	Wear ring	4	17	Wear ring	4	17	Wear ring	4	17	Wear ring	4	18	Piston seal	4	18	Piston seal	4	18	Piston seal	4
	18	Piston seal	4	18	Piston seal	4	18	Piston seal	4	18	Piston seal	4	27	Seal washer	2	27	Seal washer	2	27	Seal washer	2
	27	Seal washer	2	27	Seal washer	2	27	Seal washer	2	27	Seal washer	2	29	O-ring	4	29	O-ring	4	29	O-ring	4



<sup>\*</sup> The component parts cannot be shipped individually.


<sup>\*</sup> The MSQA (High-precision type) cannot be disassembled. Refer to page 362 for details. A grease pack (10 g) is included. When only a grease pack is needed, order with the following part number. Grease pack part no: GR-S-010 (10 g)


### Dimensions/Size 10, 20, 30, 50



With internal shock absorber High precision type MSQA□R MSQA□A/With adju MSQB□R MSQA□R/With inter

High precision type
MSQA□A/With adjustment bolt
MSQA□R/With internal shock absorber





								(mm)
Size	DH	DI	DJ	DK	DL	FE	НА	UV
10	45h8	46h8	20H8	6	15H8	10	18.5	52.5
20	60h8	61h8	28H8	9	17H8	15.5	26	63
30	65h8	67h8	32H8	12	22H8	16.5	27	67
50	75h8	77h8	35H8	13	26H8	17.5	30	76

(mm)


															-			-									` '
Size	AA	Α	AU	ΑV	AW	AX	AY	ВА	BB	вс	BD	BE	CA	СВ	D	DD	DE	DF	DG	FA	FB	FC	FD	Н	J	JA	JB
10	55.4	50	6.6	20	15.5	12	4	9.5	34.5	27.8	60	27	4.5	28.5	45h9	46h9	20H9	6	15H9	8	4	3	4.5	13	6.8	11	6.5
20	70.8	65	7.6	27.5	16	14	5	12	46	29	76	34	6	30.5	60h9	61h9	28H9	9	17H9	10	6	2.5	6.5	17	8.6	14	8.5
30	75.4	70	7.6	29	18.5	14	5	12	50	32	84	37	6.5	33.5	65h9	67h9	32H9	12	22H9	10	4.5	3	6.5	17	8.6	14	8.5
50	85.4	80	10	38	22	19	6	15.5	63	37.5	100	50	10	37.5	75h9	77h9	35H9	13	26H9	12	5	3	7.5	20	10.5	18	10.5


																									(111111)
Size	JC	JD	JJ	JK	JU	P	ø	S	SD	SE	SF	SU	U	WA	WB	wc	WD	WE	WF	XA	ХВ	хс	YΑ	YB	YC
10	M8 x 1.25	12	M5 x 0.8	7	M8 x 1	M5 x 0.8	34	92	9	13	45	17.7	47	15	3H9	3.5	M5 x 0.8	8	32	27	3H9	3.5	19	3H9	3.5
20	M10 x 1.5	15	M6 x 1	8	M10 x 1	M5 x 0.8	37	117	10	12	60	25	54	20.5	4H9	4.5	M6 x 1	10	43	36	4H9	4.5	24	4H9	4.5
30	M10 x 1.5	15	M6 x 1	8	M10 x 1	Rc 1/8*	40	127	11.5	14	65	25	57	23	4H9	4.5	M6 x 1	10	48	39	4H9	4.5	28	4H9	4.5
50	M12 x 1.75	18	M8 x 1.25	8	M14 x 1.5	Rc 1/8*	46	152	14.5	15	75	31.4	66	26.5	5H9	5.5	M8 x 1.25	12	55	45	5H9	5.5	33	5H9	5.5


<sup>\*</sup> In addition to Rc 1/8, G 1/8, NPT 1/8, and NPTF 1/8 are also available.

### **Dimensions/Size 70, 100, 200**

### Basic type/MSQB□A








View

# With shock absorber MSQB□R



																										(mm)
Size	AA	AB	Α	ΑV	AW	AX	AY	ВА	ВВ	вс	BD	BE	СВ	D	DD	DE	DF	DG	FA	FB	FC	FD	Н	J	JA	JB
70	90	92	84	42	25.5	27	8	17	75	44.5	110	57	36	88h9	90h9	46H9	16	22H9	12.5	5	3.5	9	22	10.4	17.5	10.5
100	101	102	95	50	29.5	27	8	17	85	50.5	130	66	42	98h9	100h9	56H9	19	24H9	14.5	6	3.5	12	27	10.4	17.5	10.5
200	119	120	113	60	36.5	36	10	24	103	65.5	150	80	57	116h9	118h9	64H9	24	32H9	16.5	9	5.5	15	32	14.2	20	12.5

																(mm)							
Size	JC	JD	JJ	JK	JU	Q	s	SD	SF	SU	UU	WA	WB	wc	WD	WE	WF	XA	ХВ	хс	YΑ	YB	YC
70	M12 x 1.75	18	M8 x 1.25	10	M20 x 1.5	53	170	18	79	34.2	75	32.5	5H9	5.5	M8 x 1.25	12.5	67	54	5H9	3.5	39	5H9	3.5
100	M12 x 1.75	18	M8 x 1.25	10	M20 x 1.5	59	189	22	90	34.3	86	37.5	6H9	6.5	M10 x 1.5	14.5	77	59	6H9	4.5	49	6H9	4.5
200	M16 x 2	25	M12 x 1 75	13	M27 x 1 5	74	240	29	108	40.2	106	44	8H9	8.5	M12 x 1 75	16.5	90	69	8H9	45	54	8H9	6.5

<sup>\*</sup> In addition to Rc 1/8, G 1/8 and NPT 1/8 are also available.




# Rotary Table/Rack & Pinion Type

# MSQ Series

With External Shock Absorber

Size: 10, 20, 30, 50

### **How to Order**



Applicable Auto Switches/Refer to pages 929 to 983 for detailed auto switch specification.

7,191	P   Clad voltage   Auto Switch model   Lead wire length (m)   Pre-wired   Pre															
m			ō	140		Load volta	ge	Auto swit	ch model	Lead	wire I	ength	(m)			
Туре	Special function	entry	Indicator light	Wiring (Output)	DC		AC	Perpendicular	In-line	0.5 (Nil)	1 (M)	3 (L)	5	Pre-wired connector	Applical	ble load
				3-wire (NPN)		5 V. 12 V		M9NV	M9N	•	•	•	0	0	IC	
switch	_			3-wire (PNP)		5 V, 12 V		M9PV	M9P	•	•	•	0	0	circuit	
SW				2-wire		12 V	]	M9BV	M9B	•	•	•	0	0	_	
auto	Diagnostic indication	1		3-wire (NPN)		5 V 40 V	1	M9NWV	M9NW	•	•	•	0	0	IC	
	(2-color indicator)	Grommet	Yes	3-wire (PNP)	24 V	5 V, 12 V	-	M9PWV	M9PW	•	•	•	0	0	circuit	Relay, PLC
state	(2-color indicator)			2-wire	]	12 V	1	M9BWV	M9BW	•	•	•	0	0	_	' [0
		1		3-wire (NPN)		5 V. 12 V	1	M9NAV*1	M9NA*1	0	0	•	0	0	IC	
Solid	Water resistant (2-color indicator)			3-wire (PNP)		5 V, 12 V		M9PAV*1	M9PA*1	0	0	•	0	0	circuit	
	(2-color indicator)			2-wire		12 V	1	M9BAV*1	M9BA*1	0	0	•	0	0	_	
o switch		Grommet	Yes	3-wire (NPN equiv.)	_	5 V	_	A96V	A96	•	_	•	-	_	IC circuit	_
dauto	_	Gronnet		2-wire 24 V	10.1/	100 V	A93V*2	A93	•	•	•	•	_	_	Relay,	
Beed			No		24 V	12 V	100 V or less	A90V	A90	•	_	•	_	_	IC circuit	PLC

- \*1 Although it is possible to mount water resistant type auto switches, note that the rotary actuator itself is not of water resistant construction.
- \*2 1 m type lead wire is only applicable to D-A93.
- \* Lead wire length symbols: 0.5 m ······ Nil (Example) M9NW 1 m ······ M (Example) M9NWM
  - 3 m ····· L (Example) M9NWL 5 m ····· Z (Example) M9NWZ
- Refer to pages 970 and 971 for the details of solid state auto switch with pre-wired connector.


\* Auto switches marked with a "O" are produced upon receipt of orders.

Connecting por

\* Auto switches are shipped together, (but not assembled).

### **Specifications**






The service life of the shock absorber may be different from the rotary table body depending on the operating conditions. Refer to Specific Product Precautions for the suitable replacement period.

### Symbol





# Made to Order Order (Refer to page 360 for details)

_		•
Symbol	Specifications	/Description
-X232	With external adjust	ment bolt

### Allowable Kinetic Energy and Rotation Time Adjustment Range

	0:	Allowable kinet	ic energy (J) Note 1)	Rotation time adjustment range				
	Size	Shock absorber for low energy	Shock absorber for high energy	for stable operation (s/90°)				
	10	0.161	0.231					
	20	0.574	1.060	0.2 to 1.0 Note 2)				
ĺ	30	0.805	1.210	0.2 to 1.0				
	50	1.310	1.820					

Note 1) If operated where the kinetic energy exceeds the allowable value, this may cause damage to the internal parts and result in product failure. Please pay special attention to the kinetic energy levels when designing and during operation to avoid exceeding the allowable limit.

Note 2) Values above indicate the time between the start of rotation and the deceleration caused by the shock absorber. Although the time required by the rotaty table to reach the rotation and after deceleration differs depending on the operating conditions (neitral amoment of the load, rotation speed and operating pressure), approximately 0.2 to 2 seconds are required. The range of angles within which the shock absorber operates is between the rotation end and the values shown below.

Size	10	20	30	50
For low energy	7.1°	6.9°	6.2°	9.6°
For high energy	8.6°	8.0°	7.3°	10.5°

### Weight

(q)


	Size	10	20	30	50
Doois tune	90° specification	600	1150	1460	2390
Basic type	180° specification	570	1090	1390	2280
High precision	90° specification	670	1340	1690	2720
type	180° specification	640	1290	1620	2600

Note) Values above do not include auto switch weight.




### **Rotation Direction and Rotation Angle**

- · The rotary table turns in the clockwise direction where the A port is pressurized, and in the counter-clockwise direction when the B port is pressurized.
- By adjusting the shock absorber, the rotation end can be set within the ranges shown in the drawing.



### Symmetric type




#### With external shock absorber

With Catchila Shool	a absorber
Size	Adjustment angle per rotation of angle adjustment screw
10	1.4°
20	1.2°
30	1.1°
50	1.3°

Note) - The drawings show the rotation range for the top positioning pin hole of the table.

The pin hole position in the drawing shows the counter-clockwise rotation end when the shock absorbers are tightened equally and the rotation is adjusted to 180° and 90°.

### Construction



Component parts

00	ipoliciit parts		
No.	Description	Material	Note
1	End cover	Aluminium alloy	Painted
2	Table	Aluminium alloy	Anodized
3	Arm	Chrome molybdenum steel	Nickel plated
5 6	Shock absorber holder	Aluminium alloy	Anodized
5	Hexagon socket head set bolt	Stainless steel	
6	Hexagon socket head set bolt	Stainless steel	
7	Hexagon nut	Steel wire	
- 8	Shock absorber	_	

<sup>\*</sup> The component parts cannot be shipped individually.

### Replacement parts


Description		Kit	no.		Nete
Description	10	20	30	50	Note
Seal kit	P523010-6	P523020-6	P523030-6	P523040-6	Seal washer @ is excluded from the kit contents described on page 351.





<sup>\*</sup> The MSQA (High-precision type) cannot be disassembled. Refer to page 362 for details. A grease pack (10 g) is included. When only a grease pack is needed, order with the following part number. Grease pack part no: GR-S-010 (10 g)

### Dimensions/With External Shock Absorber Size: 10, 20, 30, 50

# Basic type/MSQB $\square_{H}^{L}\square$








Effective depth **FB** øDĘ øDF øDG 2 x JC depth JD s

øDD

øΒ

Note 1) This part is not available with 180° specification.

øDL



										(mm)
Size	DH	DI	DJ	DK	DL	FE	НА	NE	NF	UV
10	45	46	20H8	6	15H8	10	18.5	11	18	52.5
20	60	61	28H8	9	17H8	15.5	26	17	25.5	63
30	65	67	32H8	12	22H8	16.5	27	18	26.5	67
50	75	77	35H8	13	26H8	17.5	30	18.5	29.5	76

View


																	(mm)												
Size	AA	Α	BA	ВВ	вс	BD	CA	СВ	D	DD	DE	DF	DG	EA	EB	EC	ED	EE	EF	FA	FB	FC	FD	GA	GB	GC	GD	GE	Н
10	55.4	50	9.5	34.5	27.8	60	4.5	28.5	45	46	20H9	6	15H9	52.9	44.3	33.5	14	97.2	80	8	4	3	4.5	20	15.6	11	7.5	45.2	13
20	70.8	65	12	46	29	76	6	30.5	60	61	28H9	9	17H9	61.8	55.3	43	18	117.1	100	10	6	2.5	6.5	25	19.5	14	9.5	56.4	17
30	75.4	70	12	50	32	84	6.5	33.5	65	67	32H9	12	22H9	63.1	60.3	46	19.5	123.4	110	10	4.5	3	6.5	27	21.5	14	9.5	61.5	17
50	85.4	80	15.5	63	37.5	100	10	37.5	75	77	35H9	13	26H9	86.8	71.4	56	22	158.2	130	12	5	3	7.5	32	28	18	11.5	72.9	20


																										(111111)
Size	J	JA	JB	JC	JD	K	NA	NB	NC	ND	Р	Q	S	SD	SE	SF	UU	WA	WB	wc	WD	WE	WF	YA	YΒ	YC
10	6.8	11	6.5	M8 x 1.25	12	M8 x 1	10	5.5	12.5	4	M5 x 0.8	34	92	9	13	45	47	15	3H9	3.5	M5 x 0.8	8	32	19	3H9	3.5
20	8.6	14	8.5	M10 x 1.5	15	M10 x 1	14	8	16.5	4	M5 x 0.8	37	117	10	12	60	54	20.5	4H9	4.5	M6 x 1	10	43	24	4H9	4.5
30	8.6	14	8.5	M10 x 1.5	15	M10 x 1	14	8	16.5	4	Rc 1/8*	40	127	11.5	14	65	57	23	4H9	4.5	M6 x 1	10	48	28	4H9	4.5
50	10.5	18	10.5	M12 x 1.75	18	M14 x 1.5	19	8.5	19.5	6	Rc 1/8*	46	152	14.5	15	75	66	26.5	5H9	5.5	M8 x 1.25	12	55	33	5H9	5.5

<sup>\*</sup> In addition to Rc 1/8, G 1/8, NPT 1/8, and NPTF 1/8 are also available.

### **Proper Auto Switch Mounting Position at Rotation End**

### • Size: 1 to 7





When D-M9 is used


When D-F8 is used

				Solid state	auto sw	itch		
Size	Rotation	D-I	И9□(V), D-M	9□W(V)	D-F8□			
Size		Α	Operating angle θ m	Hysteresis angle	В	Operating angle θ m	Hysteresis angle	
1	190°	20.9	49°	10°	16.9	20°	10°	
2	190°	22.8	50°	10°	18.8	20°	10°	
3	190°	24.4	47°	10°	20.4	15°	10°	
7	190°	28.7	31°	10°	24.7	15°	10°	

Operating angle  $\theta$  m: Value of the operating range Lm of a single auto switch converted to an axial rotation angle. Hysteresis angle : Value of auto switch hysteresis converted to an angle.

Note) Since the above values are only provided as a guideline, they are not guaranteed.

In the actual setting, adjust them after confirming the auto switch operating condition.



		Solid state auto switch					Reed auto switch					
Size	Rotation	0	-M9□	(V), D-M9□	W(V)	D-A9□, D-A9□V						
		Α	В	Operating angle θ m	Hysteresis angle	Α	В	Operating angle θ m	Hysteresis angle			
10	190°	31	49	37°	5°	27	45	53°	10°			
20	190°	39	66	33°	5°	35	62	50°	10°			
30	190°	43	72	29°	5°	39	68	43°	10°			
50	190°	53	87	22°	5°	49	83	33°	10°			
70	190°	58	99	21°	5°	54	95	30°	10°			
100	190°	65	112	18°	5°	61	108	27°	10°			
200	190°	85	143	15°	5°	81	139	21°	10°			

Operating angle  $\theta$  m: Value of the operating range Lm of a single auto switch converted to an axial rotation angle.

Hysteresis angle : Value of auto switch hysteresis converted to an angle.

Note) Since the above values are only provided as a guideline, they are not guaranteed.

In the actual setting, adjust them after confirming the auto switch operating condition.



# MSQ Series Made to Order

Please contact SMC for detailed specifications, lead times and prices.




# 1 With External Stopper

Symbol -X232

By reducing the effective stroke of the shock absorber, the absorption time will be reduced, enabling the cycle time to be improved.


### **How to Order**



### **Specifications**

Size	Allowable kinetic energy (J)							
Size	Shock absorber for low energy	Shock absorber for high energy						
10	0.161	0.231						
20	0.574	1.060						
30	0.805	1.210						
50	1.310	1.820						

- Note 1) The allowable kinetic energy indicated in the table is the value for the case where the full stroke of the shock absorber is used. Note that if the effective stroke of the shock absorber is shortened using the hexagon socket head set screw, the allowable energy will be lower than the value in the table.
- Note 2) If you wish to adjust the stroke of the shock absorber in order to reduce the cycle time, first set the shock absorber to the position where the shock absorber is to be used in the full stroke, then while observing the operating condition of the product, gradually adjust the stroke in the direction such that the effective stroke decreases
- Note 3) The shock absorber is a consumable part. If there are signs, such as bounding of the shock absorber at the motion end point, that the energy absorption performance of the shock absorber has deteriorated, readjust the position of the shock absorber so as to increase its effective stroke. If bounding still occurs even when the full stroke is used, it is necessary to replace the shock absorber with a new one.



Note) This part is not available with 180° specification.

360



10 47.4 4.5

20 62 4.5

**30** 67.6 4.8 **50** 80 7



# MSQ Series Specific Product Precautions 1

Be sure to read this before handling the products. For safety instructions as well as rotary actuator and auto switch precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual" of each product on the SMC website: https://www.smcworld.com

### Speed Adjustment

### **.**⚠Warning

 Perform speed adjustment gradually from the low speed side.

Speed adjustment from the high speed side can cause product damage leading to human injury and damage to equipment and machinery.

### **∧** Caution

 When operating at high speed with a large load weight, a large amount of energy is applied to the actuator and can cause damage.

Refer to the model selection on page 32 to find the proper operating time.

Do not machine the fixed orifice of the port to enlarge its size. If the fixed orifice size is enlarged, the actuator operating speed and impact force will increase and cause damage.

#### Lubrication

### **↑** Caution

1. Use the product without lubrication.

This product is lubricated with grease at the factory, and further lubrication will result in a failure to meet the product's specifications.

#### **Rotation Adjustment**

### **⚠** Caution

1. As a standard feature, the rotary table is equipped with a rotation adjustment screw (adjustment bolt or shock absorber) that can be used to adjust the rotation. The table below shows the rotation adjustment per single rotation of the rotation adjustment screw.

Please refer to following pages for the rotation direction, rotation angle and rotation angle range.

MSQ size1 to 7

→ page 344

MSQ size10 to 200 → page 349 MSQ with external shock absorber → page 356

With adjustment bolt. With external shock absorber

Size	Rotation adjustment per single rotation of rotation adjustment screw
1	8.2°
2	10.0°
3	10.9°
7	10.2°
10	10.2°
20	7.2°
30	6.5°
50	8.2°
70	7.0°
100	6.1°
200	4.9°

### With external shock absorber

Size	Rotation adjustment per single rotation of rotation adjustment screw
10	1.4°
20	1.2°
30	1.1°
50	1.3°

The rotation adjustment range for the external shock absorber is  $\pm 3^{\circ}$  at each rotation end. When adjusted beyond this range, note that the shock absorber's durability may decrease.

### **Rotation Adjustment**

# **⚠** Caution

MSQ Series is equipped with a rubber bumper or shock absorber. Therefore, perform rotation adjustment in the pressurized condition (minimum operation pressure: 0.1 MPa or more for adjustment bolt and internal shock absorber types, and 0.2 MPa or more for external shock absorber type.)

#### **Shock Absorber**

### **⚠** Caution

 Refer to the table below for tightening torques of the shock absorber setting nut.

Size	10	20	30	50	70	100	200
Tightening torque N · m	1.67	3.	14	10.8	23	3.5	62.8

Never rotate the bottom screw of the shock absorber. (It is not an adjustment screw.) This may cause oil leakage.



3. When rotation of the rotary table with internal shock absorber is set at a value smaller than the table below, the piston stroke becomes smaller than the shock absorber's effective stroke and energy absorption capacity decreases.

Size	10	20	30	50	70	100	200	
Minimum rotation without energy absorption capacity decrease	52°	43°	40°	60°	71°	62°	82°	

- 4. Products with shock absorber are not designed to smooth stop but to absorb the kinetic energy of the load. If the load has to be stopped smoothly, a shock absorber of the optimum size meeting the operating conditions must be installed external to the equipment.
- Shock absorbers are consumable parts. When a decrease in energy absorption capacity is noticed, it must be replaced.

#### With internal shock absorber

The state of the s							
Size	Shock absorber model						
10	RBA0805-X692						
20	DD 41000 VC00						
30	RBA1006-X692						
50	RBA1411-X692						
70	DD 40045 V004						
100	RBA2015-X821						
200	RBA2725-X821						

#### With external shock absorber

WILLI CALC	With external shock absorber									
Size	Type	Shock absorber model								
10	For low energy	RB0805								
10	For high energy	RB0806								
20	For low energy	RB1006								
20	For high energy	RB1007								
30	For low energy	RB1006								
30	For high energy	RB1007								
50	For low energy	RB1411								
50	For high energy	RB1412								



# MSQ Series Specific Product Precautions 2

Be sure to read this before handling the products. For safety instructions as well as rotary actuator and auto switch precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual" of each product on the SMC website: https://www.smcworld.com

Service Life and Replacement Period of Shock Absorber

### **⚠** Caution

 Allowable operation time under the specifications set in this catalog is 1 million.

Note) Specified service life (suitable replacement period) is the value at room temperature (20 to 25°C). The period may vary depending on the temperature and other conditions. In some cases the absorber may need to be replaced before the allowable operation time above.

### **External Shock Absorber**

### **∧** Caution

Abrasion powder may be generated from the part where the shock absorber collides with the arm. Do not use the product in a place where abrasion powder may affect adversely.

### Speed Controller and Fittings

### **∧** Caution

Size 1, 2, and 3 use M3 x 0.5 piping ports. When connecting a speed controller or fittings directly, use the following series.

Speed controller

AS12□1F/Elbow type

AS13□1F/Universal type

One-touch fitting

One-touch miniature fittings KQ2 series

Miniature fittings M3 series

#### Auto switch

### 

In case of sizes 1, 2, 3 and 7, when 2 pieces of auto switches are installed in one switch groove, the minimum detectable rotation angles are as follows.

Size	Minimum detectable rotation
1	25°
2	25°
3	20°
7	20°

### Maintenance and Inspection

### **.** Caution

Since sizes 1, 2, 3 and 7 require special tools, they cannot be disassembled.

Since sizes 10, 20, 30 and 50 have the table press fit into an angular type bearing, they cannot be disassembled.